

**CLoc® 4000 Series Stud Assembly Installation with SK-4P3 Pliers**



- (1) Grip Cup lip with SK-4P3 pliers so that the crosspin is 90 degrees to the pliers.



- (2) Compress spring

- (3) Slide stud assembly through grommet. When spring is relaxed, the assembly is captive.



## Installing SK4002-FW Series Fastener

